

STATE OF OKLAHOMA BOARD OF TESTS FOR ALCOHOL AND DRUG INFLUENCE

Dr. Jarrad Wagner, Ph.D. F-ABFT Chairman

Post Office Box 36307 Oklahoma City, Oklahoma 73136-2307 Phone: (405) 425-2460 Fax: (405) 425-2490 www.bot.ok.gov

Joshua Smith Director

ATTESTATION

I, the undersigned *Joshua Smith* (Director/Records Custodian), attest under oath pursuant to 12 O.S. §2902 (11)(a) this record was made, at or near the time of the occurrence of the matters set forth by or from information transmitted by a person having knowledge of those matters; was kept in the course of the regularly conducted business activity of the Board; and was made pursuant to the regularly conducted activity. The duplicate record provided is listed below:

1) The attached "Service Overview" is a true and accurate copy of maintenance performed on the Intoxilyzer 8000, serial number , in compliance with the agency's Maintenance Policy and Procedures.


This packet consists of pages.

Signed _____

Name of Position: Director/Records Custodian

Date of Attestation:

Service Overview



3600 N. Martin Luther King Bldg #9 Oklahoma City, OK 73111 405-425-2460

BENCH CHECK DATE: 07-17-2020

SERIAL: 80-004086

DOCUMENTATION WITHIN SERVICE PACKET:

- BOT Certificate of Calibration and Operation
- Bench Check
- Bench Check Technician's Report
- BOT Dry Gas Certificate of Analysis
- Mock Subject Test
- BOT Certificates of Analysis on Certified Solutions (4)



STATE OF OKLAHOMA BOARD OF TESTS FOR ALCOHOL AND DRUG INFLUENCE

Administrative Office at: Board of Tests for Alcohol and Drug Influence Post Office Box 36307 Oklahoma City, Oklahoma 73136-2307

Certificate of Calibration and Operation

This is to certify that the calibration of INTOXILYZER 8000, serial number 80-004086, manufactured by CMI Inc., a subsidiary of MPD, Inc. of Owensboro, Kentucky, was tested and found to be in compliance with National Highway Traffic Safety Administration Standard for Devices to Measure Breath Alcohol (F.R., No. 179 48705-48710 Sept. 17, 1993) and with International Recommendation OIML R 126 Edition 1998 (E). Calibration solutions are traceable to NIST standard material 1828.

In addition the operational procedures and functions of this Intoxilyzer have also been tested and found to be in compliance with the Oklahoma Board of Tests for Alcohol and Drug Influence - Rules and Regulations OAC Title 40: 25-1-2 and 30-1-3 and is hereby certified for use as an evidential breath testing device within this state.

CERTIFICATION TYPE	DATE
Manufacturer Calibration	05-13-09
Board of Tests Bench Check	06-01-09
Board of Tests Bench Check	05-09-11
Board of Tests Bench Check	02-23-13
Manufacturer Calibration	03-26-14
Board of Tests Bench Check	04-01-14
Manufacturer Calibration	05-16-16
Board of Tests Bench Check	11-08-16
Board of Tests Bench Check	02-28-17
Board of Tests Bench Check	10-22-18
Board of Tests Bench Check	07-17-20



Presentation of this form certifies that the Intoxilyzer, SN: 80-004086, functioned properly at the time of the breath test and hereby certifies the breath test result as valid.

Date:

Re: Request for Log of Test on Intoxilyzer 8000

Name:

Dear Sir:

The Log of Test information from a breath test conducted on a Intoxilyzer 8000 is printed in Section 2 of the Affidavit and is no longer retained as a separate form as with the Intoxilyzer 5000. The 8000 uses a nitrogen/ethanol dry gas for the external control test. The dry gas cylinder has the capacity to perform approximately 325 tests and does not require maintenance until its expiration date or can no longer provide the required pressure to perform a control test. The cylinder has an expiration date of two years from date filled at the manufacturer and is programmed in the 8000 upon installation, both dates are printed in Section 2 of the Affidavit. The Intoxilyzer is programmed to disable itself when the date of expiration is reached or the pressure monitor indicates 25 lbs psi.

Due to the reliability and stability of dry gas, maintenance on the 8000 is not required every 30 days or 25 tests, therefore maintenance is no longer performed by officers in the field. The Board of Tests for Alcohol and Drug Influence certifies each Intoxilyzer 8000 for field use by performing a bench check. The bench check is designed to check the operation and procedures programmed in the 8000 to ensure it is functioning properly for use in Oklahoma. A bench check is performed every time a new dry gas cylinder is installed or the instrument has returned from the manufacturer for repair. Once the instrument passes the bench check, all that is required to set it up for field use is to plug it in and turn it on and does not require a permit to set up. The Board of Tests has the ability to monitor each instrument once it is set up in the field.

Each Intoxilyzer has a database of valid permit numbers that it checks prior to allowing a breath test to be performed. The database is updated on a regular basis, if a permit number is invalid that officer will not be able to conduct a breath test on the 8000. If the 8000 prints an affidavit the breath test operator listed in Section 2 had a valid permit at the time of the test and the breath test is valid.

If you have any further questions please feel free to call me.

Sincerely,

J. Robert Blakeburn (OBA11059) State Director of Tests for Alcohol

O. pohr Michelium

and Drug Influence

STATE OF OKLAHOMA - BOARD OF TESTS FOR ALCOHOL AND DRUG INFLUENCE CMI INTOXILYZER BENCH CHECK PROCEDURE REPORT

	ENCH CHECK DATE 07/17/2020	08:02		80-004086			
Diagnostics	Trument TYPE Intoxilyzer						
Mouth Alcohol Test	ALVI-A-T		TEST F	RESULTS	-/		
Mouth Alcohol Test							
Mouth Alcohol Test	Diagnost	tics					
## PASS RFI Test	101674 02						
RFI Test	Mouth Alcoh	ol Test					
PASS Duplicate Breath Sampling Results	PASS	3					
PASS Duplicate Breath Sampling Results	RFI Tes	st					
No Sample Test PASS PASS			1		Company Services	77.00	
PASS Value Test 1 Test 2 Control Test	Abort Te	est	Ь	uplicate Breath	Sampling Re	esults	
PASS			Value	Test 1	Test 2		
Interferent Detect Test		40 P. V. S. P. V. S. S.	-				
PASS No Sample Given Test PASS Insufficient Sample Test PASS Air Blank Contamination Test PASS	PASS	3	.02	0.016	0.016	0.017	
10 0.095 0.093 0.096	Interferent Det	tect Test	.04	0.035	0.035	0.036	
No Sample Given Test PASS Insufficient Sample Test PASS Air Blank Contamination Test PASS	PASS	3	.10	0.095	0.093	0.096	
Insufficient Sample Test PASS PASS Air Blank Contamination Test PASS	No Sample Giv	ven Test					
PASS Air Blank Contamination Test PASS	PASS		.20	0.193	0.191	0.194	
Air Blank Contamination Test PASS	Insufficient Sar	mple Test		PA	SS		
PASS	PASS						
	Air Blank Contam	ination Test					
Range Exceeded Test	PASS						
	Range Exceed	led Test					
PASS	PASS						
		100000000000000000000000000000000000000	a sector to the Court Court of	OT A TABLE TO SEE	N DO THE LINES	A CONTRACTOR OF THE PARTY OF TH	
CERTIFYING TECHNICIAN							
swear under penalty of perjury that in regards to the above listed instrument, I have complie	ATURE	in Checking Fi	ocedure approve	d by the state o			
swear under penalty of perjury that in regards to the above listed instrument, I have complient intoxliyzer Bench Checking Procedure approved by the State of Oklahoma.	/ //				DATE		
swear under penalty of perjury that in regards to the above listed instrument, I have complient intoxliyzer Bench Checking Procedure approved by the State of Oklahoma.					0	7-17-202	
swear under penalty of perjury that in regards to the above listed instrument, I have complied the Intexhiyzer Bench Checking Procedure approved by the State of Oklahoma.	MITH JOSHUA				PERMIT#	01.600.7	
swear under penalty of perjury that in regards to the above listed instrument, I have complied the Intoxliyzer Bench Checking Procedure approved by the State of Oklahoma. DATE O7-17-20	IVITTH (IOSHVIA				10000	いけんりつつ	

3600 N. Martin Luther King Bldg #9 Oklahoma City, OK 73111 405-425-2460

BENCH CHECK TECHNICIAN'S REPORT

Intoxilyzer Model	5	erial#	
8000		80-004086	
GAS CANISTER		WD D .	
LOT#		XP Date	0.0
14020000 AL	# 003	07/05/20	u
REFERENCE	Mark Production	(37.64)	
0 11 0100	Simulator		0 # 0400
Guth 2100	Guth 2100	Guth 2100	Guth 2100
DR3591	DR3468	DR3667	DR3754
DIXOOST	Concen		DI(3754
.02	.04	.10	.20
	LOT	· <u>#</u>	
19050	19080	20190	20160
	Manufactu		
02/04/2019	03/04/2019	04/06/2020	03/18/2020
	Expiratio	n Date	
02/04/2021	03/04/2021	04/06/2022	03/18/2022
	Solution Comr	mission Date	
07-07-20	07-07-20	07-07-20	07-07-2
01-01-00	0,010	01-01-0-	01-01-0
	ICH CHECK CYLINDER REPLA NG PROUTINE M		
프랑 이 나이 하를 보았다면 사람들이 살을 때 그리고 있다.			
COMMENTS			
그렇게 하는데 이글 사내지는 사람들이 그리고 계계하다.			
프랑 이 나이 하를 보았다면 사람들이 살을 때 그리고 있다.			
COMMENTS	337		
COMMENTS	337		
COMMENTS	337		
	337		



ician Name and Signature 7 Eastgate Dr. BOX, 790 • Jacksonville, IL 62651-0790

In accordance with BOT Policy and Procedure Statement 即外2245/2018写作手式。277-243-7634 • www.ilmoproducts.com referenced dry gas cylinder is suitable for use as an external reference with the Intoxilyzer 8000.

Certificate of Analysis

Certificate ID:

13020

Part #:

BAC105L080T

Cylinder Size:

105L

Lot Number:

14020080A1

Expiration:

7/5/2022

0.080 BAC (For the calibration of instruments used to determine breath alcohol concentration)

Contents:

105 Liters @ 1000 psig 70°F (21°C)

Analytical

Reported

Accuracy

Analytical Method:

Component:

Concentration:

(U, k=2): Metl

Ethanol Nitrogen 208 ppm Balance

[5.2 ppm]

+/-0.002 BAC(G/210L) NDIR

Distributed by:

CMI Inc.

316 East Ninth Street Owensboro, KY 4230 Phone 866-835-0690 www.alcoholtest.com

Operator 5 Signature

7/13

q/210L

0.000

0.081

0.000

0.082

0.000

0.081

0.080

0.000

0.080

0.000

0.080

0.000

0.080

0.000

0.080

0.000

0.080

0.000

0.080

0.000

0.0804

0.0006

0.8696

SN 80-003400

07:57

Time

07:58

07:58

07:59

07:59

08:00

08:00

08:00

08:01

08:01

08:02

08:02

08:02

08:03

08:03

08:04

08:04

08:05

08:05

08:06

08:06

08:06

ALPHA UNIT SUB

Model 8000

07/17/2020

Test

Air Blank

Cal Check

Air Blank

Std Deu Rel Std Deu(%)

Cal Check Stats Average

Intoxilyzer - Alcohol Analyzer

*Traceable to:

Certified Reference Material - 262.4 µmol/mol

Ethanol in Nitrogen - Serial No. GN0015026 Lot No. 050319E11

Store in dry area, away from sources of heat, ignition and direct sunlight. Do not allow storage area to exceed 52 °C (125 °F).

Spegialty Gas Lab Tech

06-15-2020 Issuance Date PJLA
Calibration and Testing

Accreditation #61895

The calibration results within this certificate were obtained using equipment and standards capable of producing analytical results traceable to NIST, and apply only to the items contained on this certificate. ILMO Products Company makes no warranty or representation as to the suitability of the use of any information provided for any particular purpose. The information use is at the sole discretion and risk of the user. Liability shall be limited to established replacement cost of this material or service.

8/13

OFFICER'S AFFIDAVIT AND NOTICE OF REVOCATION/DISOUALIFICATION

	R	EVOCAT	TION/DIS	SQUA	LIFI	CATIO	N			Section
ARREST DATE 07/17/2020		ARREST TIME		COUNTY #		27	CITATIC			Bection
ARREST LOCATION N		10000			CITY	24 /	1101	COUNT		N (7)
SUBJECT NAME	ECT TEST					OF BIRTH 3/09/196	51 N	RACE	LAHO HEIGHT 51(WEIGHT
ADDRESS 3600 MARTII		KING A	OKLA	HOMA C			STATE		ZIP CO.	DE .
DRIVER LICENSE # T083454871		***************************************		EXPIRATION D.	ATE	STATE C	LASS A	RESTRI N	CTIONS	ENDORSEMENTS N
VEHICLE MAKE NONE	, , , , , , , , , , , , , , , , , , , ,	MODEL NONE			1	AG# NONE		STATE	CMV N	PLACARD N
On the above date, time, and lochighway, street, turnpike, public influence of alcohol and/or other (Describe driving behavior or circ MOCK SUBJECT Describe person's condition (odd	parking lot, or other publintoxicating substances cumstances): TEST . ROU	lic place, or upon a private as prohibited by law.	road, street, alley or lan	e which provides	access to one	or more single or m	/sical contro ulti-family d	l of a motor ve welling within t	hicle upor his state v	n a public road, while under the
NONE										
		THE PERSON W	VAS INFORMED OF TH	E IMPLIED CON	SENT TEST I	REQUEST				
BREATH-ALCOHOL ANALYSIS	RECORD, REPORT O			and LOG OF TE	ST AND MAIN	TENANCE RECOR	D.			Section 2
EQUIPMENT I-8000 STANDARD Dry		SERIAL N 80 -		PECIALIST BOARD	OF TE	1BER				
MANUFACTURER ILMO			140200	80 A 1	DATE CYLIN	DER INSTALLED 7/2020		ATE CYLINDE		
OBSERVATION START TEST	7/17/2020	MOUTHPIECE G			<u>-</u>	on/observatio		07703	/ 2.02	<u> </u>
RESULT TABLE Test	g/210L	Time	period was	s observed pe time of tes	rior to an t adminis	d continuing tration.		(a)	THE	TATE
Air Blank Subject Test Breath Volume Air Blank Wait Air Blank Subject Test Breath Volume Air Blank	0.00 0.00 1.968 LITER 0.00 0.00 0.00 2.003 LITER 0.00	10:29 10:31 10:32 10:32	compliance	e with the lure of the	applical	ole operatin		STABAT SE	190	
Cal Check	0.08	10:33	NAME SMITH, JOS	АПН				•	Test Re	
Air Blank	0.00	10:33	BADGE # 000004		PERMIT #	016837			rAC g/	
			AGENCY BOARD OF						0.0	00
days or more, if you refused or (operating a CMV or CDL hold as a result of this arrest by filin You may be eligible to partic revocation as a result of this request IDAP within thirty (3: SERVING OF NOTICE: Accountability Program to Date served: 07/1:	failed the state's test er) OR a test result of g a petition in the Dist ipate in the Impairec arrest from appeari o) days of the date li I personally hand o the person name	s). In addition, your com .04 or more while operat icit Court of the County in I Driver Accountability I og on your driving reco sted below. Mail the re- delivered a copy of t ed in Section 1 above	imercial driving privileg ing a commercial mold n which you were arres Program (IDAP) admi rd. Participation in II quest for IDAP to the he above containing.	ge in this state wor vehicle. You rested. Your petiti inistered by the DAP may reduce Department of the Notice	ill be disqual may appeal a con must be fix Departmen te the amount Public Safe	fied if you refused ny Departmental a led within thirty do t of Public Safety nt of fees you will ty at P.O. Box 114 tion and the No	or failed the ction again () days of the (DPS). Color be required to the ctice of Decision of the ctice of Decision of Decisio	e state's test(st your driver ne date listed empletion of ed to pay to oma City, Ol	s) license below. IDAP ma the State 73136.	. You must
In accordance with Title 1			nalty of perjury ur	nder the laws	of Oklaho	ma that the fore	going is	true and co	rrect."	Section 4
Date: 07/17/202	U Place (location	n when signed):		AGENCY	Signatur	e of arresting of	ficer:			
SMITH, JOSH BADGE 0000000435	IUA agency address INTER-A	GENCY		BOARD	OF T	ESTS ZIP CODE 00000	PHONE	42524	160	
OTHER WITNESSES:	TIVILLY A					100000	1 + 03	42524	. 0 0	Section 5
NAME		.,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	TITLE	ADDRESS			РНО	NE		Section 3
1 NAME			TITLE	ADDRESS			PHO	NE		
2]							

No Temporary License Issued: Test Below Legal Limit

9/13

OFFICER'S AFFIDAVIT AND NOTICE OF REVOCATION/DISQUALIFICATION

Sact	

								Dection i
ARREST DATE	ARREST TIME	COUNTY #	CIT	Y #	CITATIO	ON#		
07/17/2020	0930	55	2	7	NO	NE		
ARREST LOCATION		CI1	ГҮ			COUNTY	,	
N						OKI	LAHO	MA
SUBJECT NAME			DATE OF		SE:	X RACE	HEIGHT	WEIGHT
MOCK, SUBJECT TEST			08/	09/19	961 N	Λ W	510	165
ADDRESS		CITY			STATE		ZIP COD	E
3600 MARTIN LUTHER	KING A	OKLAHOMA CIT	Y		OK		731	.33
DRIVER LICENSE #		EXPIRATION DATE		STATE	CLASS	RESTRIC	CTIONS	ENDORSEMENTS
T083454871		06/30/20	019	OK	Α	N		N
VEHICLE MAKE	MODEL		TAG	S #		STATE	CMV	PLACARD
NONE	NONE		N	ONE		OK	N	N

On the above date, time, and location, the above named person was arrested, and I had reasonable grounds to believe the person was driving or in actual physical control of a motor vehicle upon a public road, highway, street, tumpike, public parking lot, or other public place, or upon a private road, street, alley or lane which provides access to one or more single or multi-family dwelling within this state while under the influence of alcohol and/or other intoxicating substances as prohibited by law.

(Describe driving behavior or circumstances):

MOCK SUBJECT TEST. ROUTINE MAINTENANCE. NEW GAS CANISTER INSTALL

Describe person's condition (odor, actions, etc.):

NONE

THE PERSON WAS INFORMED OF THE IMPLIED CONSENT TEST REQUES:

		THE PERSON V	VAS INFORMED OF THE I	MILLIED CONSENT	TEST REQUEST	
BREATH-ALCOHOL ANALYSIS	RECORD, REPORT OF TH	IE PERSON NAMED	IN SECTION 1 ABOVE, an	d LOG OF TEST A	ID MAINTENANCE RECORD.	Section 2
EQUIPMENT				CIALIST		
I-8000		80-	·004086 B	OARD OF	TESTS	
STANDARD			TARGET VALUÉ	1	MIT NUMBER	
Dry			0.080		5837	
MANUFACTURER			LOT#		CYLINDER INSTALLED	DATE CYLINDER EXPIRES
ILMO			1402008	0A1 0.	7/17/2020	07/05/2022
	DATE	MOUTHPIECE	A 15-minute (or greater) der	rivation/observation	
	7/17/2020	G	,		to and continuing	
RESULT TABLE				time of test ad		THE STATE
Test	g/210L	Time	to the	or test ad	iiiiiisti atioii.	
			T 1	1 '17	1 A1 1 1 m	2/***
Air Blank	0.00	10:29	I administere	d said Brea	th-Alcohol Test in	BANTA
Subject Test	0.00	10:29	compliance v	with the app	olicable operating	
Breath Volume	1.968 LITERS		procedure of the Board of Tests.		2 + + 1 - 1 - 1 - 1 - 1 - 1 - 1	
Air Blank	0.00	10:29	procedu	re or the be	bard of Tests.	F. **/
Wait		10:31				
Air Blank	0.00	10:32				
Subject Test Breath Volume	0.00 2.003 LITERS	10:32	SIGNATURE OF OPE	RATOR		1907
Air Blank	0.00	10:32				
Cal Check	0.08	10:32	NAME			Test Result
Air Blank	0.08	10:33	SMITH, JOSH	UA		
AII DIGIIK	0.00	10.55	BADGE #	PER		BrAC g/210L
			000000043	5 00	000016837	0.00
			AGENCY			
			BOARD OF ?	FESTS		L

EFFECTIVE THIRTY (30) DAYS FROM DATE SERVED. Notice of Revocation is given that your driver's license is revoked or denied for a period of one hundred eighty (180)

days or more, if you refused or failed the state's test(s). In addition, your commercial driving privilege in this state will be disqualified if you refused or failed the state's test(s)
(operating a CMV or CDL holder) OR a test result of .04 or more while operating a commercial motor vehicle. You may appeal any Departmental action against your driver license as a result of this arrest by filing a petition in the District Court of the County in which you were arrested. Your petition must be filed within thirty (30) days of the date listed below. You may be eligible to participate in the Impaired Driver Accountability Program (IDAP) administered by the Department of Public Safety (DPS). Completion of IDAP may prevent a revocation as a result of this arrest from appearing on your driving record. Participation in IDAP may reduce the amount of fees you will be required to pay to the State. You must request IDAP within thirty (30) days of the date listed below. Mail the request for IDAP to the Department of Public Safety at P.O. Box 11415, Oklahoma City, OK 73136.

SERVING OF NOTICE: I personally hand delivered a copy of the above containing the Notice of Revocation and the Notice of Department Impaired Driving Accountability Program to the person named in Section 1 above.

Date served: 07/17/2020 Signature of officer:			Badge #:		
In accordance with Title 12 O.S. Section 426, "I state under penalty of perjury under the laws of Oklahoma that the foregoing is true and correct."					
Date: 07/17/2020 Place (location when signed):	Signate	ure of arresting off	icer:		
NAME TO CLIFTA	AGENCY	mnama			
SMITH, JOSHUA	BOARD OF '	TESTS			
BADGE AGENCY ADDRESS		ZIP CODE	PHONE		
0000000435		00000	4054252460		

No Temporary License Issued: Test Below Legal Limit

Certificate of Analysis - Wet Bath 928 12-10-19 Date of Analysis Labelled targer ralue (g/210L) 020 19050

ABORATORIES, INC.

590 NORTH 67th STREET 9 HARRISBURG, PA 17111-4511 9 TELEPHONE: 717-564-5470

BOT Technician Name and Signature

Lot Number

BRT Form 6.0

In accordance with BRT - 2.2.0, Maintenance, the above referenced simulator solution is suitable for use as an external reference in maintenance of the Intoxilyzer 8000.

CERTIFICATE OF ANALYSIS

RLPHA INSTRUMENT 2 Intoxilyzer - Alcohol Analyzer Model 8000

12/10/2019

5N 80-004923 Certified Alcohol Reference Solution for Simulator

Test g/210L Time Air Blank 0.000 14:53 Cal Check 0.019 14:53 Air Blank 0.000 14:54 Cal Check 0.020 14:55 Air Blank 0.000 Cal Check 0.019 14:56 Air Blank 0.000 14:56 Cal Check 0.020 14:57 Air Blank 0.000 14:58 Cal Check 0.019 14:58 Rir Blank 0.000 14:59 Cal Check 0.020 15:00 Air Blank 0.000 15:00 Cal Check 0.019 15:01 Rir Blank 0.000 15:01 Cal Check 0.020 15:02 Air Blank 0.000 15:02 Cal Check 0.020 15:03 Air Blank 0.000 15:04 Cal Check 0.020 15:04 Air Blank 0.000 Cal Check Stats Average 0.0196 Std Deu 0.0005 Rel Std Deu(%) 2,6345

Random Samples of Lot Number 19050 Alcohol Reference Solution for Simulator were analyzed by chromatography on February 5, 2019, using a Perkin Elmer Gas gas Chromatograph Autosystem XL S/N: 610N9030209, and found to contain 0.0236% (w/vol) ethyl alcohol. The expiration date for this lot number is February 4, 2021 at 11:59 PM.

When used in a calibrated Simulator, operating at 34°C +/- .2°C, this solution will give a breath alcohol analysis instrument reading of 0.020 g/210L +/- 3%.

The alcohol and water used in this solution were free of test interfering substances.

ator's Signature

Ted L. Pauley, President GUTH LABORATORIES, INC.

NIST Traceability:

Testing was conducted using Cerilliant Reference Standard lot number FN08031603 whose values are traceable to NIST.

All balances are calibrated annually by an outside agency using NIST traceable weights. Calibration verification is done prior to each use utilizing NIST traceable weights.

Certificate of Analysis - Wet Bath 840 12:10-19 Date of Analysis tar R value (g/210L) . 040 19080



BORATORIES, INC.

Lot Number

590 NORTH 67th STREET . HARRISBURG, PA 17111-4511 . TELEPHONE: 717-564-5470

BOT Technician Name and Signature

BRT Form 6.0

In accordance with BRT - 2.2.0, Maintenance, the above referenced simulator solution is suitable for use as an external reference in maintenance of the Intoxilyzer 8000.

CERTIFICATE OF ANALYSIS

ALPHA INSTRUMENT 2 Intoxilyzer - Alcohol Analyzer Model 8000 SN 80-004923 12/10/2019 15:16

Certified Alcohol Reference Solution for Simulator

Test g/210L Time Air Blank 0.000 15:17 Cal Check 0.040 15:17 Air Blank 0.000 15:18 Cal Check 0.040 15:19 Air Blank 0.000 15:19 Cal Check 0.040 15:20 Air Blank 0.000 15:20 Cal Check 0.040 15:21 Air Blank 0,000 15:22 Cal Check 0.040 15:22 Air Blank 0.000 15:23 Cal Check 0.040 15:24 Air Blank 0.000 15:24 Cal Check 0.040 15:25 Air Blank 0.000 15:25 Cal Check 0.039 15:26 Air Blank 0.000 15:27 Cal Check 0.039 15:27 Air Blank 0.000 15:28 Cal Check 0.039 15:29 Air Blank 0.000 15:29 Cal Check Stats Average 0.0397 Std Dev 0.0004

Random Samples of Lot Number 19080 Alcohol Reference Solution for Simulator were analyzed by chromatography on March 5, 2019, using a Perkin Elmer Gas gas Chromatograph Autosystem XL S/N: 610N9030209, and found to contain 0.0481% (w/vol) ethyl alcohol. The expiration date for this lot number is March 4, 2021 at 11:59 PM.

When used in a calibrated Simulator, operating at +/- .2°C, this solution will give a breath alcohol analysis instrument reading of 0.040 g/210L +/- 3%.

The alcohol and water used in this solution were free of test interfering substances.

ator's Signature

1,2167


Rel Std Deu(%)

Ted L. Pauley, President GUTH LABORATORIES, INC.

NIST Traceability:

Testing was conducted using Cerilliant Reference Standard lot number FN12181501 whose values are traceable to NIST.

All balances are calibrated annually by an outside agency using NIST traceable weights. Calibration verification is done prior to each use utilizing NIST traceable weights.



BONATORIES, INC.

BRI FORM 6.0 71SE JRG, PA 17111- 4511 . TELEPHONE: 717-564-5470

In accordance with BRT - 2.2.0, Maintenance, the above referenced simulator solution is suitable for use as an external reference in maintenance of the intoxilyzer 8000.

CERTIFICATE OF ANALYSIS

ALPHA INSTRUMENT

Intoxilyzer - Alcohol Analyzer Model 8000 06/16/2020

16:18

SN 80-002591 Certified Alcohol Reference Solution for Simulator

fest 9/210L Time lir Blank 0.000 al Check 0.099 16:19 ir Blank 0.000 16:20 al Check 0.098 16:20 ir Blank 0.000 16:21 al Check 0.097 16:22 ir Blank 0.000 16:22 al Check 0.098 16:23 ir Blank 0.000 16:24 al Check 0.098 16:24 r Blank 0.000 16:25 il Check 0.098 16:26 r Blank 0.000 16:26 1 Check 0.098 16:27 r Blank 0.000 16:27 I Check 0.097 16:28 Blank 0.000 16:29 1 Check 0.098 16:29 Blank 0.000 16:30 1 Check 0.098 16:31 Blank 0.000 16:31 Check Stats erage 0.0979 d Deu

Random Samples of Lot Number 20190 Alcohol Reference Solution for Simulator were analyzed by gas chromatography on April 8, 2020, using a Perkin Elmer Gas Chromatograph Autosystem XL S/N: 610N9030209, and found to contain 0.1206% (w/vol) ethyl alcohol. The expiration date for this lot number is April 6, 2022 at 11:59 PM.

When used in a calibrated Simulator, operating at 34°C +/- .2°C, this solution will give a breath alcohol analysis instrument reading of 0.100 g/210L +/- 3%.

The alcohol and water used in this solution were free of test interfering substances.

Signature Operator

0.5798

1 Std Deu(%)


Ted L. Pauley, President GUTH LABORATORIES, INC.

NIST Traceability:

Testing was conducted using Cerilliant Reference Standard lot number FN02271802 whose values are traceable to NIST.

All balances are calibrated annually by an outside agency using NIST traceable weights. Calibration verification is done prior to each use utilizing NIST traceable weights.

\$C1220



Christapher

_PHR UNIT 5UB htoxilyzer - Alcohol Analyzer

odel 8000

7/07/2020

ist

ir Blank

al Check

ir Blank

al Check

ir Blank

31 Check

ir Blank

31 Check

ir Blank

al Check ir Blank

al Check ir Blank

al Check

ir Blank

al Check

ir Blank

al Check

ir Blank

al Check

ir Blank

Std Deu

al Check Stats Average ,

Rel Std Deu(%)

BOT Technician Name and Signature

q/210L

0.000

0.196

0.000

0.196

0.000

0.197

0.000

0.196

0.000

0.000

0.000

0.197

0.000

0.198

0.000

0.198

0.000

0.197

0.000

0 1971

0.0008

0.4442

SN 80-003400

15:25

Time

15:26

15:26

15:27

15:28

15:28

15:29

15:29

15:30

15:31

15:31

15:33

15:34

15:35

15:35

15:36

15:37

15:37

15:38

SUTH LABORATORIES, INC.

550 NORTH 97th STREET . HARRISBURG, PA 17111-4511 . TELEPHONE: 717-584-5470

BRT Form 6.0

In accordance with BRT – 2.2.0, Maintenance, the above referenced simulator solution is suitable for use as an external reference in maintenance of the Intoxilyzer 8000.

CERTIFICATE OF ANALYSIS

Certified Alcohol Reference Solution for Simulator

Random Samples of Lot Number 20160 of
Alcohol Reference Solution for Simulator were analyzed by
gas chromatography on March 20, 2020, using a Perkin Elmer Gas
Chromatograph Autosystem XL S/N: 610N9030209, and found to contain
0.2427% (w/vol) ethyl alcohol/ The expiration date for this lot
number is March 18, 2022 at 11:59 PM.

When used in a calibrated Simulator, operating at 34°C +/- .2°C, this solution will give a breath alcohol analysis instrument reading of 0.200 g/210L +/- 3%.

The alcohol and water used in this solution were free of test interfering substances.

Operator Stonature

Ted L. Pauley, President GUTH LABORATORIES, INC.

NIST Traceability:

Testing was conducted using Cerilliant Reference Standard lot number FN08101505 whose values are traceable to NIST.

All balances are calibrated annually by an outside agency using NIST traceable weights. Calibration verification is done prior to each use utilizing NIST traceable weights.